Audiovox CDM 8500/8600/8910/8615/8930
Programming with ONE TIME LOCK CODE

1. Turn the phone on. Newly unprogrammed phones for the first time should display "***Programming Required"*** on screen.
2. Enter **[#] [#] [2] [0] [0] [2] [2] [0] [0] [2] [END]**. This will take you to the initial menu.
3. Enter the **One Time subsidy Lock Code**.

4. The following menu will appear:

    1. Dir Number
    2. Phone Number
    3. Homesys ID

5. **Press (1)** to select **"Dir Number"** and enter the assigned **10-digit phone number**.
6. Press **<STO/OK>** to confirm entry.
7. To finish NAM programming press **<END>.**
8. Phone will power cycle to complete the programming.